



ECO-THERM Do-It-Yourself Instructions - Brush Quality

Important: Should not be applied at working temperatures below +5°C. Absolutely avoid frost in the next few days after application. The coating should be able to harden.

Preliminary work:

Clean the surface of grease, oil, rust, loose particles, etc.

Dilution:

ECO-THERM- Anti-condensation coating is delivered ready to use.

ECO-THERM - Anti-condensation coating must always be stirred well before use.

ECO-THERM - Anti-condensation coating can be diluted with a maximum of 4% water.

Recommended layer thickness:

We recommend a consumption of 1,000 grams per m². Corresponds to a layer thickness of 1.0 mm

Painting:

First coat: paint several times with a brush in the same direction (very thin layer, acts as a primer)

ECO-THERM - anti-condensation coating should be evenly distributed over the entire surface

Second and possibly third coat: apply **ECO-THERM** - anti-condensation coating also in the same direction (brush acts as spatula)

Drying time:

Drying time at a layer thickness of 1.0 mm, 25 degrees Celsius and 55% relative humidity:

- Touch dry: approx. 3 hours
- Dry: 8 hours
- Fully cured: 48 hours

Ensure that at least the recommended film thickness is always applied. The drying time is about 1-2 days. Depending on the outside temperature.

Cleaning:

Brushes and tools are cleaned with water.

www.eco-therm.at | www.antikondensat.at | www.korrotech.at

Korrotech - Beschichtungstechnik GmbH
Gewerbestraße West 20 A-4921 Hohenzell